



Important Note

For power the system we use the USB connector. It is important to insert the juper on JP1.

The JP1 is located on the LEFT of USB connector.

TITLE: Car Parking Assistant		REV: 1.0
Company: WWW.EMCU.EU		Sheet: 1/1
Date: 2019-04-26	Drawn By: EMCU	